Wake up number key — 🗶 #	Registration management user The top three are administrators Please register a 6-digit administrator password Easy to operate by mobile phone	INTELLIGENT ELECTRONIC LOCK SIMPLE OPERATION MANUAL
< EXPERIMENTAL Control of Control	management (1979) (1979) (1970	
Door care Door I Volume	d management d management lock voice a navigation ary password E + E + E + E + E + E + E + E + E + E +	
Family Member Other Member Inter	Extra version Unidexing functions (a) Unions: innoign mainteent (b) Unions: innoign mainteent (c) Unions:	

Long press the initialization key to restorethe factory settings of the system The first three users are administrators

PRODUCT PARAMETERS

Category	Detailed technical parameters		
working voltage	INPUT: DC 6V		
Standby power supply voltage	USB Micro Interface power supply: DC 5~7V		
Matching fingerprint sensor type	Semiconductor sensorv		
Password keyboard	Capacitive touch keyboard		
Number of keys	12Key (0~9,#Key to confirm ,* key to cancel)		
Language mode	Chinese or English voice navigation		
Quiescent current	≤70uA		
Dynamic current	≤300mA		
Drive output	Direct		
Driving load capacity	≤300mA		
Low voltage alarm voltage	≤4.8V(When the power supply voltage is lower than the standard 80±5%, it indicates that the battery is dead)		
Fit card type	IC-₩		
Attendance Record	10000 Strip		
working temperature	-25°C~+65°C		
Storage temperature	-40°C~ + 80°C		
Working humidity	5~95%RH (No condensation)		
Total capacity	1000		
Single password	1000		
Single card	1000		
Single fingerprint	100 Pieces		

Bluetooth connection steps

Gateway

(Optional)

Wiring free switch (Optional)

all Pilles T	8/61 AM			8.02			
	B /DT AN	0 0	<	Add Manually		5-	
			Gernaure.	Milio Servella			
			Large Horse Applications				
	0		Smal Home Appliances	Smart Camera (Wi-Pè	Smart Cornera (Duel Band)	Smart Carrier (BLE)	
			Kitchen Apphances	0			
	Add Device		Ucerchia & Heolth	Smart Cemera (40)	Smert Doorbell	Reodight Canara	
	-		Becurity & Video Garo	Base Station	No.11	CV/R	
			Caltoway Control	base contain	Smarritock		
			Duitclo or Traver	1.	1.	1.	
			Energy	Lock (Wi-Fb	Lock (7 lgbeet)	Lock (BLE)	
			Entantalone m	1	1		
٠	Ø.	Ø	Entority & Agricultum	Lock (Ndi-IsT)	Lock (dG)		
Open '	graffiti	app"		ect "de	ವುದರಿ ಮಂ	0.000	
Click	Add de	evice	moi	nthe nitorin Bluet	g"op	tion	
a tilet P	8.53 46				414	041	

e 🕶 🖂	aromes≉ ×	8.63 AM	₽ 4 B .)
5		s. Added 0 successfully.	Add A4
arara.	I 25940		•
e P	- 蓝牙语		0
RgM Iora			
P			
El			
	Display	ed by sca	annin
y		oth lock	
n		Add devid	

color "+" number

864 AM 亚牙根

Q.4.8

018

Remote control

(Optional)

1.Restore factory settings Initialization is through the hole above the rear lock button, press for more than 6 seconds, and the system prompts [initialization is successful], and the system returns to the factory state

2.Normally open setting After verifying the key or fingerprint unlocking, press the "2, 8" key to enter the normally open mode, voice broadcast "has entered the normally open mode", and then the system enters the sleep state; Any valid key will automatically exit the normally open mode after unlocking.

3. Quick operation

A: "0#"One key lock

4.Function test

Press 1 # (input administrator password), press #, confirm and press 0 to open, press * to exit





Orange after successful Click the pen behind addition" + "The number the Bluetooth lock to modify the lock name will turn green

After adding, press and hold to unlock